

Brainbees Solutions Pvt. Ltd. Corporate & Registered Office Address: Rajashree Business Park, Plot No: 114, Survey No. 338, Tadiwala Road, Near Sohrab Hall, Pune 411 001

Customer Care:

- **③** 020 30556310
- customercare@brainbees.com

Made in PRC




Before using the stroller read the manual thoroughly and carefully.

Keep the manual handy for any future reference

Folding Instructions


- Brake the rear wheels and stop the swiveling of the front wheels by drawing the clip
- Remove the carrycot from the stroller as shown in Fig. 12a
- Unlock the second lock as shown in Fig. 12b
- As shown in the Fig. 12c, slide rings and press down the handle at the same time
- As shown in the Fig. 12 d and 12 e, put the folding hook in place to keep it compact





Dismantling the Stroller:

How to Remove:

- **Bumper Rail or Handrail** Press down the side buttons and remove the rail as shown in Fig.13
- Front Wheels Press the button on the wheels with one hand, as shown in Fig.14, and remove the front wheels with the other hand
- Rear Wheels Press the button on the wheels with one hand, as shown in Fig. 15, and remove the rear wheels with the other hand









Assembly Instructions:

Unfold the Baby Stroller

- Take the stroller out of the package as shown in Fig. 1a
- Unfold the folding hook, pull the handlebar and gradually push to open the stroller until a "click" sound is heard as shown in Fig. 1b and 1c








Install the Front Wheels

As shown in Fig. 2, attach each wheel to the front wheel axle till a "click" sound is heard.






Warning

- Inspect the stroller properly every time before placing your baby in it
- · Never leave your baby unattended in the stroller
- Do not hang or place anything so heavy on the handle that the stroller becomes prone to tipping over backwards
- Before use make sure all the locking devices are inspected and secure
- The stroller is designed for babies between 0 to 36 months (0 to 6 months while using as carry cot) and maximum carrying capacity is 15 kg (9 kg while using as carry cot)
- Objects in the net basket should not weigh more than 2 kg
- The product is not suitable for running or skating
- Always use the brake when the stroller is in stationary mode
- · Keep the product away from fire
- · Always use the product on smooth and even surface

Maintenance


- For cleaning the fabric, remove the screw and take it out of the stroller
- Wipe the fabric lightly with natural soap and cold water. Let it air dry Babyhug liquid laundry detergent is best recommended
- · Do not bleach, press or dry clean the fabric of the stroller
- Wipe the metal and plastic parts of the stroller with a wet cloth. Do not use harsh chemicals for cleaning
- Keep checking the stroller for loose screws, damaged parts or broken threads
- While dismantling or assembling the stroller, follow the instructions on the user manual carefully

08



Install the Rear wheel

As shown in Fig. 3, insert the rear wheels into the rear wheel axle till a "click" sound is heard and ensure the rear wheels are locked and cannot be pulled out.





Install the Bumper Rail or Handrail

As shown in Fig. 4, insert the rail into the body of unit and press down till a "click" sound is heard.

Carry Cot Installation


The carry cot comes pre-assembled. Plug it on to the adapters as shown in Fig 5a and 5b.






Safety Harness

- The belt comes in three parts. Simply insert the male parts on the shoulder and side belts into the female part of the crotch belt and press slightly to lock as shown in Fig. 11a,11b,11c & 11d
- To disengage the lock, press the button on the belt and then pull apart
- The safety harness can be removed while the baby is between the ages of 0 to 6 months and generally lies in the carry cot as shown in Fig 11e
- When the child learns to sit up, the safety harness can be installed as shown in Fig 11f,11g,11h
- As shown in Fig 11i, the safety harness should always be used for children aged between 6 to 36 months







03

Canopy


As shown in Fig. 9a, 9b, 9c, 9d and 9e the canopy can be folded or unfolded by pushing or pulling its front edge backward or forward.





Front Swivel Wheel

If the fixed clip is raised, the front wheels will swivel. If the fixed clips are pushed down, the front wheels can't swivel around the front pipe as shown in Fig. 10a.



Using the Rear Wheel Brakes

Use your feet to lift the brake pole upward to release the brakes, and push it downward to apply the brakes as shown in Fig. 10b.

05

Seat Adjustment

The position of the seat can be adjusted with the help of buttons present on the stroller. Buckle the belt at the back, as shown in Fig. 6a Buckle the belt on both sides of the carry cot as shown in Fig. 6b Press the side buttons and adjust the carry cot as shown in Fig. 6c









Seat Reversal

To reverse the seat just disconnect the carry cot from the frame by pressing down the two side buttons, change its direction and fix it onto the connectors again as shown in Fig. 7a, 7b, 7c and 7d.









Handle Height Adjustment

Press the buttons on both sides of the handle to adjust handle height as shown in Fig. 8a and 8b.

04

