

Care

- Regularly check the tightness of bolts and tighten as necessary.
- Check for damage which could render your rocker unsafe or cause splinters.
- To clean use a soft cloth, avoiding the use of strong detergents or abrasives.
- An occasional light application of a wax polish will help maintain a good appearance.

Safety Warning

- The rocker should always be locked when the child is unsupervised.
- Young children should not be allowed to play in the vicinity of the rocker.
- The rocker should always be placed on a firm and level surface.
- A mat size of 100 cm in length and 560 cm in width is suggested
- The thickness of the mattress should be such that the distance from the top of the mattress to the top of the rocker sides should not be less than 20 cm.
- Do not leave anything in the rocker or place the rocker near items, which could provide a foothold or present a danger of suffocation or strangulation.
- All assembly fittings should always be tightened properly and fittings should be checked regularly and re-tightened as and when necessary.
- Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of this rocker and do not place it near windows or other furniture.
- When the child is able to sit, kneel or pull itself up, the rocker should not be used anymore for this child.

Imported & Marketed by

Brainbees Solutions Pvt. Ltd.
Corporate & Registered Office Address:
Rajashree Business Park, Plot No: 114,
Survey No. 338, Tadiwala Road,
Near Sohrab Hall, Pune 411 001

Customer Care No. :

02030556310

E-mail:

customercare@brainbees.com

Customer Care Address:

Same as Importer's address

Made in China



- Rocking Function
- 3- Level Height Adjustment
- Wheels For Mobility
- Storage

Please read the instructions carefully before use and keep this manual for future reference.

Contents



Bed Board : 1



Foldable Side : 1



Fixed Side : 1



Head Board : 1



Foot Board : 1



Storage Board : 1



Extension Support Bar : 2



M6*35 mm Bolts : 11



M6*35 mm Club Bolts : 2



Storage Board Hooks : 4



Bed Board Brackets And Screws : 6



Caster Wheels : 4



Caster Wheels Blind Nut : 4 , Bolts : 4



Spanner : 1

Assembly Instructions



• As shown in figure 1, bring the straight side boards, the head and foot boards together and join them with 8 M6*35 mm bolts



• As shown in figure 2, fix the foldable side with the head board



• As shown in Figure 3, install the storage extension support on the head board. Install the lower end of the supporting rod and fix it to the elbow of the moving track. The upper end is fixed with M6*35 bolt



• As shown in figure 4, fix the storage board hooks on the lower part of the side boards. The hooks are designed to hold and support the storage board in place. Lower the board on to the hooks



• As shown in figure 5, the bed board has to be placed above the storage board. Place the bed board brackets and hooks as indicated in the figure. Lower the bed board on to the hooks



• As shown in figure 6, fix the caster wheels on to the foot of the rocker with M6*30 mm bolts. Use the spanner and cross screwdriver to tighten the bolts and screws



• Fold caster wheels to use as rocker