

## Warning

- 1) Always secure the child with restraint belts until the child is able to get in and out of the product without help.
- 2) Always secure the product on a chair using the bottom and back attachment straps.
- 3) Never use this product on a stool or bench that does not have a backrest.
- 4) Do not use in motor vehicles.
- 5) Never leave child unattended when in use.

## Care & Maintenance

- 1) Before assembly and each use, inspect the product for damaged hardware, loose joints, missing parts or sharp edges. DO NOT use if any parts are missing or broken.
- 2) The booster seat with attached straps and belt may be wiped clean using a mild cleaning solution and a damp cloth. Babyhug multi purpose liquid cleaner is recommended.

**Imported & Marketed by**  
Brainbees Solutions Pvt. Ltd.  
Corporate & Registered Office Address:  
Rajashree Business Park, Plot No: 114,  
Survey No.338, Tadiwala Road,  
Near Sohrab Hall, Pune 411001

**Customer Care No. :** 91-9607 940 940  
**E-mail:** [customercare@brainbees.com](mailto:customercare@brainbees.com)

**Customer Care Address:**  
Same as Importer's address


Made in PRC




- 3 level Height Adjustment
- Foldable Back Rest
- Safety Harness

## Assembly Instructions


### Installation of Seat




Place the booster seat on chair



Wrap the bottom straps around the bottom of the chair and then buckle them up together. Make sure you hear a "click". Pull the free end of the strap to tighten the seat on the chair



Wrap the back straps around the back of the chair and then buckle them up together. Make sure you hear a "click". Pull the free end of the strap to tighten the seat on the chair




Lift the backrest towards back and "snap" it into place.


### Secure Your Child



Place your child on the booster seat. Position the crotch belt between your child's legs.



Buckle the restraint belt to the crotch belt. Make sure you hear "click" on both the sides.





Check to be sure that the restraint system is securely buckled by pulling it away from your child.

## Usage

### Adjustable Tray

Fit the tray to the booster seat, pushing the tray down onto the tray attachment buttons. The tray can be adjusted to three different positions.



### Adjustable Height

As shown in picture, height can be adjusted to 3 different position by just pressing the button to the required height.

